
Silencing the clock

If you want to silence the QUARTERS then do so immediately after they have sounded, eg at 8.01 or 11.46. Then reactivate the quarters at the same time past the hour, eg 10.01 or 3.46 respectively.

The hour STRIKE can be silenced and unsilenced at any time.

Please don't leave the clock silenced for any longer than necessary.

QUARTERS – lift the lever and insert the large silencing disc as shown. Re-activate by removing the disc.





STRIKE – push the silencing bar to the right and insert the spacer as shown. Re-activate by removing the spacer.

